


GP49L
front part train
126 cm long x 33 cm wide x 67 cm height
+/- 52 kg



GP49W
Back part train (add-on)
120 cm long x 33 cm wide x 67 cm height
(2cm overlaps the front part)
+/- 49 kg

Mounting

The equipment is delivered fully assembled and requires no extra mounting. Anchoring on hard ground is required.

Material

- Solid boards made of recycled plastics (PE) coloured throughout (beige, green, brown)
- Stainless steel screws and nail plugs
- Replaceable plastic steering wheels (PP)

Maintenance

The plastic material requires very little maintenance, that is cleaning with soapy water and a sponge or soft brush and rinsing with water to remove dirt and soap. As the materials' water absorption is less than 0.29%, it will not get stained by oil, grease or other products. Moss and algae will not adhere easily and can easily be removed. Cleaning with high-pressure (max. 100 bar) is possible but not recommended and mostly even not necessary. Spray with a fan-shaped jet with minimum 30 cm distance from the surface. Painting or staining is useless as the material does not need extra protection and moreover the paint will not stick to the plastic.

Inspection Requirements

Visual inspection:

Weekly or monthly, depending on the intensity of use.

Functional inspection:

Monthly or four-monthly, depending on the intensity of use.

Detailed inspection:

Yearly

Special attention during functional or detailed inspection:

- Check all parts are tight.
- Check worn, loose, damaged, missing parts.
- Check screws sticking out.
- Check anchoring on hard soil.
- Steering wheels must be tightly secured.
- Vandalism?
- Space on the steering wheels

Use original Govaplast parts when repairing is required, to ensure the TÜV certificate remains valid.

Installation

The installation needs to be done on a hard and even surface. The equipment cannot be installed on a loose surface such as a sandpit, wood chips, bark mulch, unless a special bearing construction is installed (not standard).

Security Zone

An obstacle-free area of minimum 150 cm around the equipment is required.

No fall absorption surface required

The equipment's fall height is less than 60 cm. Therefore it's allowed to install it on a hard surface.

Anchoring is required

Each train part is anchored by fixing the 8 stainless steel nail plugs supplied into the countersunk holes. Place the equipment and then drill the holes for the nail plugs through the pre-drilled holes with an 8 mm stone drill. Finally place the nail plugs.


Important advice:

To drill the holes use a sharp drill and first put the plastic part of the plug in the hole. Then screw the metal nail into the plug instead of hammering it. This way, you avoid damaging the head of the nail and unfixing will be easy.



24x

Example: L+W+W




$$L+W+W+W+W= 597 \text{ cm}$$

$$L+W+W+W= 479 \text{ cm}$$

$$L+W+W= 361 \text{ cm}$$

$$L+W= 243 \text{ cm}$$



Replacement steering wheels

Through intensive use, the plastic mechanism in the steering wheel is subject to wear. The wearing of the wheel and the other plastic parts, causes play on the system involving necessary replacement after a few years.

The wheel can't come loose from the green plastic mounting plate, as the cap nut is permanently glued onto the metal shaft. Replacing the whole system is not difficult though, as the green plastic mounting plate together with the wheel can be unscrewed from the board/post/play and a new steering system can be screwed.

